

Allen R. Shuffleboard Company Inc.

Phone 1-800-260-3834

(727) 398-8877

(727) 398-4661

Web: www.shuffleboard-1.com

STEPS TO ASSEMBLY

1	1A
2	2A
3	3A
4	4A
5	5A
6	6A
7	7A
8	8A
9	9A
10	10A
11	11A
12	12A
13	13A
14	14A
15	15A
16	16A
17	17A
18	18A
19	19A
20	20A

BOX # 1
Sections
1-7A

BOX # 2
Sections
8-13A

BOX # 3
Sections
14-20A

BOX # 4

*Champion and Deluxe
Courts ONLY
STANDING AREAS

1. Open box Number 4 and take out 6 sections of BURGUNDY TILES.

2. Place the 6 sections of BURGUNDY tiles at one end of the court, and place the remaining 6 sections at the other end of the court. Do not snap these together yet.

3. Open BOX #1 and lay the tiles out as the diagram shows. This box has sections 1-7A

4. Open Box #2 and lay the tiles out as shown. This box has the 12 unpainted sections 8-13A

5. Open Box #3 and lay the tiles out as shown. This box has sections 14-20A

6. Now snap the 3 green sections together.

7. Attach the 6 BURGUNDY sections to each end.

Additional Instructions

1. Wash the Poly Court with water using garden hose pressure. We do not recommend pressure cleaning them. Soap can be used if necessary, however water seems to be the best.
2. When taking your Poly Court apart for storage, we recommend leaving the trim attached.
3. The use of a Silicone Spray on the bottom of your discs will make the disc slide faster.